

Candlewicking on the Husqvarna Viking Sapphire Sewing Machine

Candlewicking is fun and easy. A technique originally stitched by hand, it is easy to program the Candlewick stitch on your Husqvarna Viking Sapphire Sewing Machine. The Candlewicking Foot has a deep tunnel on the underside to feed over a built up stitching. Program a “French Knot” stitch on your Husqvarna Viking Sapphire sewing machine to sew the heirloom candlewicking technique.

1. Snap on your Candlewicking Foot #412510845. (Sold as an accessory)
2. Thread with sewing thread or 40 wt. rayon embroidery thread on top and in the bobbin. Place stabilizer underneath the fabric.
3. Touch PROG.
4. Touch a Straight Stitch. Adjust the stitch length if desired. (This stitch is the distance between the Candlewick “Knots”.)
5. Touch zig zag. Adjust the length to 0. Adjust the width to 2.
6. Touch OK on the Navigator Button 6 times to enter the zig zag. At a length of 0 a total of 7 times.
7. Begin to sew.

