




Husqvarna Viking Clear S Foot

412 9751-45

1 (#1+ (1250), #1 (1200), (1100). 7

Husqvarna Viking owners have requested a see-through S foot to make it even easier to see Omnimotion stitches as they sew and as they quilt and embellish with this wider foot that applies more all over pressure onto the project.



- For Omnimotion stitches, Scallop stitches or 4 way stitches.
 - Makes beautiful borders or edgings on your tablecloths.
 - A Clear center portion for good visibility while sewing.
1. Thread with desired thread top and bobbin.
 2. Snap on the Husqvarna Viking Clear S Foot.
 3. To insure a straight line of stitching, mark a center line on the fabric with your Pictogram Pen where the center of the stitching will be.
 4. Select a stitch from the K Menu, Ommimotion, Stitches, H Menu, Scallop stitches.
 5. Place the fabric with Tear-Away Stabilizer underneath the presser foot. Lower the needle into the marked line. Sew carefully and let the machine control the feeding. Occasionally, touch the STOP button. The machine should stop with the needle on the marked line. If it off slightly, re-position the fabric so you are back on the marked line.
 6. If you are sewing a scallop edge, apply a fray stopping liquid just outside the scallop stitching so it “wicks” back onto the stitching. Allow to dry. Trim the fabric outside the scallop.
 7. Tear away the excess stabilizer.