

Even Feed Foot/Walking Foot/Dual Feed Foot

Husqvarna Viking Mega Quilter
#416 04 84 01

Machine Settings:
Thread tension: 4-5
Stitch length: 2-4
Foot pressure: 3-5

The Even Feed foot "walks" over fabric to assist with keeping fabric layers feeding at the same rate. With this foot, fabric can be sewn without shifting or puckering since the fabric is gripped and fed by both upper and lower feed teeth. It feeds well with materials such as plaids, knit, vinyl or leather. It is also often used in quilting when sewing two layers of fabric and one of batting.

1. Place the fork (B) of the Even Feed Foot over the needle clamp screw (A) and attach the foot to the presser bar with the thumb screw.
2. Set the speed control slide to the left position and lower the presser foot and start sewing slowly.

