

IMPORTANT SAFETY NOTICE!

FOR PURCHASERS OF HUSQVARNA VIKING DESIGNER I SEWING MACHINE

Dear Husqvarna Viking Owner:

VSM Sewing, Inc. ("Husqvarna Viking") has initiated a program to refurbish or replace the power supply component on certain Husqvarna Viking Designer I sewing machines. Husqvarna Viking is implementing this recall in cooperation with the United States Consumer Product Safety Commission.

PROBLEM: Husqvarna Viking believes that a component in the power supply of the Husqvarna Viking Designer I can potentially overheat.

Husqvarna Viking believes that within a component in the power supply of its Husqvarna Viking Designer I machines there exists a minimal potential of overheating which could, in rare circumstances, cause electrical arcing. Husqvarna Viking has determined that in three Husqvarna Viking Designer I sewing machines sold from January 1999 through June 2004, the power supply component caused the machine to overheat. Husqvarna Viking changed this component in February 2004, and there have been no reported incidents involving machines manufactured after that date. Husqvarna Viking is not aware of any injuries associated with this product.

PRODUCT: Husqvarna Viking Designer I machines sold from January 1999 through June 2004 within the following serial number ranges:

- Serial number beginning with "5" and ending with "0."
- Serial number beginning with "7" and ending with "2."
- Serial number beginning with "5" and ending with "3."
- Serial number beginning with "4" and ending with "2."
- Serial number beginning with "6" and ending with "4."
- Serial number beginning with "5" and ending with "4."
- Serial number beginning with "6" and ending with "1."
- Serial number beginning with "8" and ending with "4."
- Serial number beginning with "5" and ending with "1."

Serial number beginning with “0” and ending with “6.”
Serial number beginning with “1” and ending with “9.”
Serial number beginning with “7” and ending with “4.”
Serial number beginning with “9” and ending with “1.”
Serial number beginning with “6” and ending with “3.”
Serial number beginning with “5” and ending with “9.”
Serial number beginning with “3” and ending with “1.”
Serial number beginning with “9” and ending with “5.”
Serial number beginning with “0” and ending with “0.”
Serial number beginning with “7” and ending with “1.”
Serial number beginning with “2” and ending with “3.”
Serial number beginning with “8” and ending with “2.”
Serial number beginning with “9” and ending with “3.”

WHAT TO DO: If your machine is found within the above group, please bring your machine to your nearest Husqvarna Viking dealer for a free refurbishment of the component that is subject to the recall. The component will be replaced free of charge if it cannot be refurbished or if the circumstances otherwise warrant replacement. For additional information, please contact Husqvarna Viking at (800) 446-2333 between 9:00 a.m. and 4:30 p.m. ET Monday through Friday.

The safety of our customers and the quality of our products are very important to us. We are sorry for the inconvenience this causes you. Thank you for your cooperation.